

## **Product Information**

## Cathepsin S Activity Fluorometric Assay Kit

#### I. Kit Contents:

Component	K2155-100	Cap Color	Part Number
	100 assays		
CS Cell Lysis Buffer	25 ml	WM	K2155-C-1
CS Reaction Buffer	5 ml	NM	K2155-C-2
CS Substrate Z-VVR-AFC (10 mM)	0.2 ml	Brown	K2155-C-3
CS Inhibitor (1 mM)	20 μl	Red	K2155-C-4

#### **II. Introduction:**

Apoptosis is often mediated by the traditional caspase-mediated cleavage cascade. In addition, alternative proteolytic enzymes such as the lysosomal cathepsin proteases can also initiate or propagate proapoptotic signals. Cathepsins are lysosomal proteases that play an important role in mammalian cellular turnover such as bone resorption. Cathepsins are often used as sensitive markers in a variety of toxicological investigations. Cathepsin S is a lysosomal cysteine protease belonging to the peptidase C1 family and is involved in the degradation of antigenic proteins to peptides for presentation on MHC class II molecules. Cathepsin S also plays an important role in itch and pain, or nociception.

The Cathepsin S Activity Fluorometric Assay Kit provides a sensitive, simple and convenient way for detection of cathepsin S activity based on fluorometric method. The assay utilizes the preferred cathepsin-S substrate sequence VVR labeled with AFC (amino-4-trifluoromethyl coumarin). While cleavage of the synthetic substrate Z-VVR-AFC by cathepsin-S in cell lysates or other samples, free AFC emits a yellow-green fluorescence  $(\lambda max = 505 \text{ nm})$  that can be easily quantified using a fluorescence microtiter plate reader or a fluorometer.

#### III. Cathepsin S Assay Protocol:

1. Collect cells  $(1 - 5 \times 10^6)$  by centrifugation.

Note: Use 50 - 200 µg cell lysates (in 50 µl of CS Cell Lysis Buffer) if protein concentration has been measured.

- 3. Lyse cells in 50 µl of chilled CS Cell Lysis Buffer. Incubate cells on ice for 10 min.
- 4. Centrifuge at top speed in a microcentrifuge for 5 min, transfer the supernatant to a new tube. Add 50 µl of cell lysate to a 96-well plate.
- 5. Add 50 µl of CS Reaction Buffer to each sample.
- 6. Add 2 ul of the 10 mM Z-VVR-AFC substrate (200 uM final concentration).

Note: For negative control, add 2 µl of CS Inhibitor prior to adding CS Substrate, or make a reaction mixture that does not contain sample as control.

- 7. Incubate at 37°C for 1 2 hour.
- 8. Read samples in a fluorometer equipped with a 400-nm excitation filter and 505-nm emission filter. For a plate-reading set-up, transfer the samples to a 96-well plate. You may also perform the entire assay directly in a 96-well plate.

Fold-increase in Cathepsin S activity can be determined by comparing the relative fluorescence units (RFU) with the level of the uninduced control or the negative control sample. If desired, the units of cathepsin S can be determined by generating a standard curve using free AFC under your assay conditions.

### IV. Storage and Stability:



Store kit at -20°C (Store CS Cell Lysis Buffer and CS Reaction Buffer at 4°C after opening). Protect CS Substrate Z-VVR-AFC from light. All reagents are stable for 6 months under proper storage conditions.

## **General Troubleshooting Guide for Cathepsin Fluorometric Kits:**

Problems	Cause	Solution
Assay not working	Cells did not lyse completely	• Resuspend the cell pellet in the lysis buffer and incubate as
	• Experiment was not performed at optimal time after	described in the datasheet
	apoptosis induction	Perform a time-course induction experiment for apoptosis
	• Plate read at incorrect wavelength	Check the wavelength listed in the datasheet and the filter
		settings of the instrument
High Background • Increased amount of cell lysate used		• Refer to datasheet and use the suggested cell number to
	• Increased amounts of components added due to incorrect	prepare lysates
	pipetting	Use calibrated pipettes
	• Incubation of cell samples for extended periods	Refer to datasheet and incubate for exact times
	• Use of expired kit or improperly stored reagents	Always check the expiry date and store the individual
	Contaminated cells	components appropriately
		Check for bacteria/ yeast/ mycoplasma contamination
Lower signal	• Cells did not initiate apoptosis	• Determine the time-point for initiation of apoptosis after
levels	Very few cells used for analysis	induction (time-course experiment)
	• Use of samples stored for a long time	Refer to datasheet for appropriate cell number
	• Incorrect setting of the equipment used to read samples	• Use fresh samples or aliquot and store and use within one
	• Allowing the reagents to sit for extended times on ice	month for the assay
		Refer to datasheet and use the recommended filter setting
		Always thaw and prepare fresh reaction mix before use
Samples with	• Uneven number of cells seeded in the wells	Seed only equal number of healthy cells (correct passage)
erratic readings	• Samples prepared in a different buffer	number)
	Adherent cells dislodged and lost at the time of experiment	Use the cell lysis buffer provided in the kit
	• Cell/ tissue samples were not completely homogenized	Perform experiment gently and in duplicates/triplicates;
	Samples used after multiple freeze-thaw cycles	apoptotic cells may become floaters
	• Presence of interfering substance in the sample	• Use Dounce homogenizer (increase the number of strokes);
	• Use of old or inappropriately stored samples	observe efficiency of lysis under microscope
		Aliquot and freeze samples, if needed to use multiple times
		Troubleshoot as needed
		Use fresh samples or store at correct temperatures until use
Unanticipated	Measured at incorrect wavelength	Check the equipment and the filter setting
results	• Cell samples contain interfering substances	Troubleshoot if it interferes with the kit (run proper
		controls)
General issues	• Improperly thawed components	Thaw all components completely and mix gently before use
	• Incorrect incubation times or temperatures	Refer to datasheet & verify the correct incubation times and
	• Incorrect volumes used	temperatures
	• Air bubbles formed in the well/tube	Use calibrated pipettes and aliquot correctly
	Substituting reagents from older kits/ lots	Pipette gently against the wall of the well/tubes



	• Use of a different 96-well plate	• Use fresh components from the same kit
		• Fluorescence: Black plates; Absorbance: Clear plates
Note# The most probable cause is listed under each section. Causes may overlap with other sections.		

For research use only! Not to be used in humans.

# Our promise

If the product does not perform as described on this datasheet, we will offer a refund or replacement. For more details, please visit <a href="http://www.apexbt.com/">http://www.apexbt.com/</a> or contact our technical team.

Tel: +1-(832)696-8203 Fax: +1-832-641-3177 Email: sales@apexbt.com